

Interface Settings



Scan Interface

This interface will be used for wifi discovery and all attacks except handshake and deauth


Wlan0



Handshake Interface

This interface will be used for monitor mode and handshake capture attack

Wlan1



Deauth Interface

This interface will be used for deauthing users from AP

Wlan1

Revision #1

Created 6 November 2022 18:14:23 by ZalexDev

Updated 6 November 2022 18:15:09 by ZalexDev